

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG)

Introduction Created by Hemisphere GNSS, this QRG provides information and the steps to follow to set up your Vector VR1000 GNSS Receiver.

VR1000 key features Key features of the VR1000 include:

- High-precision positioning in Athena RTK, Atlas L-band, and SBAS
- Athena technology for improved RTK performance, especially with GLONASS, Galileo, and BeiDou
- Atlas* L-band technology providing highly accurate corrections over the air (*Requires the purchase of a subscription)
- Heave of 30 cm RMS (DGNSS), 10 cm (RTK)
- Pitch and roll < 1° RMS
- Heading accuracy up to .01°

Mounting When considering where to mount the VR1000, consider the following satellite reception recommendations:

- Ensure cable length is adequate to route into the machine to reach a breakout box or terminal strip.
- Do not mount the receiver where environmental conditions exceed those specified in the VR1000 Technical Specifications of this document.
- Route cables away from any potential source of mechanical damage.



Figure 1: VR1000 GNSS Receiver

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),

Continued

Environmental considerations Hemisphere Vector GNSS Receivers are designed to withstand harsh environmental conditions; however, adhere to the following limits when storing and using the VR1000:

- Operating temperature: -40°C to +70°C (-40°F to +158°F)
- Storage temperature: -40°C to +85°C (-40°F to +185°F)
- Humidity: IEC 16750-4:2010 Section 5.6 Humid heat, cyclic test

Mounting orientation The VR1000 outputs heading, pitch, and roll readings regardless of the orientation of the VR1000. The relation of the antennas to the machine's axis determines if you need to enter a heading, pitch, or roll bias. The primary antenna is used for positioning and the primary and secondary antennas, working in conjunction, output heading, pitch, and roll values.

Parallel orientation Install the GNSS antennas parallel to, and along the centerline of the axis of the machine. **This provides a true heading.** In this orientation:

- If you use a gyrocompass and there is a need to align the antennas, you can enter a heading bias in the VR1000 to calibrate the physical heading to the true heading of the machine.
- You may need to adjust the pitch/roll output to calibrate the measurement if the receiver is not installed in a horizontal plane.

Perpendicular orientation Install the GNSS antennas perpendicular to the centerline of the machine's axis. In this orientation:

- Enter a heading bias of +90° if the secondary antenna is installed on the right side of the machine, and -90° if the secondary antenna is installed on the left side of the machine.
- Configure the receiver to specify the GNSS receiver is measuring the roll axis using the VR1000 WebUI.
- Enter a roll bias to properly output the pitch and roll values.
- You may need to adjust the pitch/roll output to calibrate the measurement if the receiver is not installed in a horizontal plane.

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),

Continued

Mounting
orientation




Figure 2: 0-degree heading bias example

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),
Continued

Mounting
orientation
example




Figure 3: 90-degree heading bias example

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),
Continued

Mounting
orientation
example,
continued




Figure 4: Negative 90-degree heading bias example

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),
Continued

Mounting
orientation
example,
continued




Figure 5: 180-degree heading bias example

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),

Continued

Mounting options

The VR1000 allows for two different mounting options: mount with bolts, or mount with magnets.

Serial port configuration

You may configure Port A or Port B of the GNSS receiver to output any combination of data.

Port A can have a different configuration from Port B in data message output, data rates, and the baud rate of the port, and configure the ports independently based upon your needs.

Note: For successful communications, use the 8-N-1 protocol and set the baud rate of the VR1000's serial ports to match that of the devices to which they are connected. Flow control is not supported.

Baud Rates & Message Types

When selecting your baud rate and message types, use the following formula to calculate the bits/sec for each message and sum the results to determine the baud rate for your required data throughput.

Message output rate * Message length (bytes) * bits in byte =
Bits/second
(1 character = 1 byte, 8 bits = 1 byte, use 10 bits/byte to account for overhead).

For information on message output rates refer to the [Hemisphere GNSS Technical Reference Manual](#).

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),

Continued

VR1000 communication specifications

Table 1 lists the communication items and technical specifications of the VR1000 GNSS receiver.

Table 1: VR1000 Communication Specifications

Item	Specification
I/O ports	2x CAN, 1x Ethernet, 2x Serial (Port A RS232, Port B RS232/RS422)
Baud rates	4800 - 115200
Correction I/O protocol	Atlas, Hemisphere GNSS proprietary, RTCM v2.3 (DGPS), RTCM v3 (RTK), CMR, CMR+ ¹ NMEA 0183, Hemisphere GNSS binary
Timing output	1PPS, CMOS, active high, rising edge sync, 10 k Ω , 10 pF load
Event marker input	CMOS, active low, falling edge sync, 10 k Ω , 10 pF load
Radio Interfaces	Bluetooth 2.0 (Class 2), Wi-Fi 2.4 GHz, UHF (400 MHz)

Power/data cable pin-out assignments, continued

For VR1000 pin-out information, refer to Table 2: VR1000 Pin-Out assignments and Figure 7: VR1000 Back Panel and Pin-Out.

VR1000 Back Panel Connector Definition:

1. PWR/Comm (23PIN x 1)
2. RADIO (TNC x 1)
3. BT/Wi-Fi (TNC x 1)
4. GNSS ANT (N-Type x 2)

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),

Continued

**Power/data
cable pin-out
assignments,
continued**

Table 2 lists the VR1000 connector pin-out. Refer to [Appendix B, Figure B-1: Cable drawing](#) for more detailed information.

Table 2: VR1000 Connector Pin-out

Pin	Description
1	CAN2 Low
2	CAN1 High
3	Ethernet RX-
4	Ethernet TX-
5	RS232 Port A Rx
6	1PPS OUT
7	Port B RS422 TX+/SPEED OUT
8/15	Power Ground
9	CAN2 High
10	CAN1 Low
11	Ethernet RX+
12	Ethernet TX+
13	RS232 Port A Tx
14	Port B RS422 RX- /EVENT MARK
16	CAN2 Shield
17	CAN1 Shield
18/19	Signal Ground
20	Port B RS232 TX/RS422 TX-
21	Port B RS232 RX/RS422 RX+
22/23	Power Positive

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),

Continued

Power/data
cable pin-out
assignments,
continued

Figure 6 shows the VR1000 back panel and pin-out.



Figure 6: VR1000 back panel and pin-out

1. Primary antenna
GNSS Primary RF +5V to power antenna
2. Secondary antenna
GNSS Secondary RF +5V to power antenna
3. Radio antenna
Radio RF
4. BT/Wi-Fi antenna
BT/Wi-Fi RF

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),

Continued

LED Indicators The VR1000 has twelve LED lights located on the front panel of the unit. Table 3 below describes each LED indicator.



Figure 7: VR1000 LED

Table 3: LED indicators

Indicator	Description/Function
Power	Solid GREEN indicates receiver is powered on
Primary GNSS	Solid GREEN indicates tracking 4+ satellites Solid RED indicates No Satellites
Secondary GNSS	Solid GREEN indicates tracking 4+ satellites Solid RED indicates No Satellites
Heading	Solid GREEN indicates 2D GNSS heading Solid AMBER indicates 2D sensor heading
Quality	Solid GREEN indicates RTK fixed Flashing GREEN (1/sec) indicates DGPS / Float Solid AMBER indicates Autonomous Flashing AMBER indicates No Position Solid RED indicates No Satellites
Atlas	Flashes GREEN each time an Atlas message is received Solid GREEN indicates Atlas locked Solid AMBER indicates Atlas activated but not locked

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),

Continued

LED Indicators,
continued

Table 3: LED indicators (continued)

Indicator	Description/Function
Bluetooth	Solid BLUE indicates Bluetooth is turned on Flashing BLUE (1/sec) indicates Bluetooth is connected
Wi-Fi	Solid GREEN indicates Wi-Fi is operational Flashing GREEN (1/sec) indicates Wi-Fi is connected
CAN1	Solid GREEN indicates CAN operational Flashing GREEN (1/sec) indicates CAN in use
CAN2	Solid GREEN indicates CAN operational Flashing GREEN (1/sec) indicates CAN in use
Ethernet	Solid GREEN indicates Ethernet operational Flashing GREEN (1/sec) indicates Ethernet in use
Radio	Flashes GREEN each time radio message is received/sent Solid GREEN indicates radio mode but no data

Continued on next page

Vector VR1000 GNSS Receiver Quick Reference Guide (QRG),

Continued

Recommendations for connecting to other devices

When interfacing to other devices, ensure the transmit data output and the signal grounds from the VR1000 are connected to the data input, and signal grounds of the other device.

The RS-422 is a balanced signal with positive and negative signals referenced to ground; ensure you maintain the correct polarity.

When connecting the transmit data output positive signal to the receive line of the other device, it should be connected to the receive positive terminal.

The negative transmit data signal from the VR1000 is then connected to the receive data negative input of the other device.

For a list of Hemisphere GNSS commands, please refer to the [Hemisphere GNSS Technical Reference Manual](#). To configure the unit through the WebUI, please refer to [Configuring the VR1000 using the WebUI](#).

Power/Data cable considerations

The VR1000 uses a single 3 m cable for power and data input/output.

The receiver end of the cable is terminated with an environmentally-sealed 23-Pin connection while the opposite end is terminated with multiple connectors. Ensure that the PWR-/B-wire is connected to a clean chassis ground. **DO NOT** ground directly to the battery.

Configuring the VR1000 Using the WebUI

Overview

The VR1000 is equipped with an onboard WebUI.


Note: The VR1000 WebUI supports Chrome and Firefox web browsers.

First, connect the Bluetooth/WiFi antenna to the connector. The receiver displays as an available Wi-Fi device in your available networks. Connect your device to the VR1000's Wi-Fi. The password is hgnss1234.

Open a web browser window and type the following IP address:
192.168.100.1

Status

The VR1000 **Status** tab displays. You can view RX Info, Position, Heading, L-band and SBAS.



Basic Status		Advanced Status	
Time			
UTC	2019-03-27 18:01:58		
Local	2019-03-27 11:01:58		
Position			
Latitude	33° 38' 36.01320" N		
Longitude	111° 53' 43.5336" W		
Altitude	455.129 m		
Heading			
Heading	69.80°		
COG	276.62°		
ROT	-0.20°/min		
YAW	-153.18°		
Pitch	87.55°		
Roll	0.08°		
Heave	0.01m		
Speed	0.03km/h		
Compass rose (hdg vs cog)	-206.82°		
Precision			
Satellites Used	15		
3D Accuracy	0.00 m 1σ (0.01 m 2σ)		
2D Accuracy	0.3 cm 1σ (0.6 cm 2σ)		
HDOP	0.7		
Solution Status			
Solution Type	RTK Fixed		
Differential Data Source	ROX		
Age of Differential	2 seconds		
L-BAND/SBAS			
Frequency	1545.9150 MHz	Signal Strength	89
Source	Atlas	DDS	992.7
Bit Error Rate	0 (OK)	Baud Rate	600bps
Carrier Lock	Yes	Satellite Longitude	-98°
DSP Lock	Yes	Configured Frequency	1545.9150 MHz
Frame Sync	Yes		

Table 4: Status fields

Field	Description
Time	UTC time obtained from satellites, Local time configured in Settings; Miscellaneous tab
Position	Latitude, Longitude, Altitude
Heading	Heading, COG, ROT, YAW, pitch, roll, heave, speed, and the difference between heading and COG
Precision	Satellites used in solution, 3D Accuracy, 2D Accuracy, horizontal dilution of precision
Solution Status	Solution type, correction source, correction signal latency
L-band /SBAS	Atlas Frequency, Source, Bit Error Rate, Carrier Lock, DSP Lock, Frame Sync, Frame Sync 2*


***Note:** For a definition of the L-band/SBAS fields refer to [Appendix A, Terms and Definitions](#).

Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Tracking

On the **Tracking** tab, the Sky Plot shows the azimuth, elevation, and SNR values of all tracked satellites.




Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Information tab On the **Information** tab, the Serial Number, Board Type, Board Firmware, Subscriptions, Devices, RX info, and Port information is displayed.

Activated items are in green.

Important: If you have purchased an activation or subscription, use the field on the **System** screen to enter the Subscription Code, and click **the 'arrows' button**.



The screenshot shows the Hemisphere VR1000 WebUI. At the top, there is a navigation bar with tabs: STATUS, TRACKING, INFORMATION (selected), FILES, SYSTEM, and SETTINGS. The main content area is divided into three sections: Basic, Receiver, and Devices.

Basic:

- Firmware Version: V1.0.1
- Device Mode: Rover
- Device Type: VR1000
- Disk Space: 3.5G/3.5G
- Time Zone: (UTC -10) Honolulu - USA

Receiver:

- Serial Number: 19501118
- Board Type: H328
- Board Firmware: 5.9Aa06

Subscriptions:

20Hz	RTK	RTK
Multi-Frequency	Multi-GNSS	RTK 3+
Atlas: Not Subscribed		

Devices:


Serial	CAN	Radio	Network
Port	Type		Baud Rate
A	RS232		19200bps
B	RS232/RS422		19200bps

Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Files tab

Use the file tab to upload files and download log files from the receiver.




System

The System tab can be used to upgrade both GNSS firmware or carrier board firmware. You can add subscription codes on this screen.

Use the buttons at the bottom of the screen:

- **Format Disk**-format the internal storage
- **Self Test**- run a receiver self-test
- **Factory Restore**- restore the unit to factory settings
- **Reboot**-reboot the unit



Note: The filesystem cannot be used when Bluetooth is enabled. If Bluetooth is enabled, an option will be given to disable Bluetooth.

Continued on next page

Configuring the VR1000 Using the WebUI, Continued


System,
continued

After Bluetooth is disabled, the filesystem displays. Any log files stored on the receiver will be available for download.

To upgrade firmware, click **Choose File**, select the GNSS or carrier board firmware, and press “Upload.”


Settings

A pop-up dialog box displays prompting for username and password. Type the UserName: admin and the password: Hemi3384.



You can configure the following using the VR1000 WebUI:

- Heading
- CAN
- Serial
- Radio
- Ethernet
- Logging
- Ntrip
- Atlas
- Miscellaneous




Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Heading menu The **Heading menu** displays the following data.

Various heading settings can also be configured.

Click the box of the desired setting and type the configuration setting values.



Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Heading menu,
continued

Table 5 lists the heading configurations.

Table 5: Heading Configurations

Heading Configuration	Description
Heading Bias	<p>Add a bias to the heading value the receiver outputs.</p> <p>Heading is defined as the direction of the vector created from the primary to secondary antenna. Heading is measured using true north.</p> <p>Range: -180 – +180</p>
Pitch Bias	<p>Add a bias to the pitch value the receiver outputs.</p> <p>If the receiver is in “roll” mode, this will add a bias to the roll instead.</p> <p>Range: -15 – +15</p>
Gyro Aiding	<p>Gyro aiding enables the use of the internal gyro sensor and allows for the continuous output of heading for up to three minutes during a GNSS outage. Gyro aiding improves the reacquisition time when GNSS heading is lost because of an obstruction in GNSS signal.</p>
Negative Tilt	<p>Change the sign of the pitch/roll measurement.</p>
Tilt Aiding	<p>Turn OFF or ON tilt aiding. When on, the sensors are used to reduce the RTK search volume – improving heading startup and reacquisition times.</p>
Flip Board	<p>N/A</p>
Level Operation	<p>If the Vector will be operated within +/- 10 degrees of level, you may use this mode of operation for increased robustness and faster acquisition times of the heading solution.</p>

Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Heading menu,
continued

Table 5: Heading Configurations (continued)

Heading Configuration	Description
Pitch/Roll Mode	<p>If the antennas are mounted such that they model pitch, set to PITCH.</p> <p>If the antennas are mounted such that they model roll, set to ROLL.</p> <p>Note: If your HBIAS is -90 or +90, set this to ROLL. If your HBIAS is 0 or 180, set this to PITCH.</p>
Heading TAU	<p>Adjust the responsiveness to true heading.</p> <p>If the machine is large and unable to turn quickly, increase this value.</p> <p>For longer baselines (10 m) HTAU should be between 0.1 and 0.5, since the gyro introduces noise.</p> <p>Default value: 0.1 s with gyro enabled Range: 0.0 to 60 s Formula: $htau (s) = 40 / \text{max rate of turn } (^\circ/s)$ <i>with gyro ON</i> $htau (s) = 10 / \text{max rate of turn } (^\circ/s)$ <i>with gyro OFF</i></p>
Heading Rate TAU	<p>Adjust the responsiveness to the rate of heading change.</p> <p>If the machine is large and unable to turn quickly, increase this value.</p> <p>Default value: 2.0 s with gyro enabled Range: 0.0 to 60 s Formula: $hrtau (s) = 10 / \text{max rate of the rate of turn } (^\circ/s^2)$</p>

Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Heading menu,
continued

Table 5: Heading Configurations (continued)

Heading Configuration	Description
COG TAU	<p>The direction the machine is moving.</p> <p>Adjust the responsiveness to the course over ground measurement.</p> <p>If the machine is small and dynamic, leave this value at 0.0 s to be conservative.</p> <p>If the machine is large and resistant to motion, increase this value.</p> <p>Default value: 0.0 s . Range: 0.0 to 60 s Formula: cogtau (s) = 10 / max rate of change of course (°/sec)</p>
Speed TAU	<p>Speed of machine in km/h.</p> <p>Adjust the responsiveness to speed.</p> <p>If the machine is small and dynamic, leave this value at 0.0 s to be conservative.</p> <p>If the machine is large and resistant to motion, increase this value.</p> <p>Default value: 0.0 s Range: 0.0 to 60 s Formula: spdtau (s) = 10 / max acceleration (m/s²)</p>
MSEP	<p>The measured distance between the primary and secondary antenna. Must be accurate to within 2 cm.</p>

Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Heading menu, continued


Table 5: Heading Configurations (continued)

Heading Configuration	Description
CSEP	<p>This is the antenna separation calculated by the receiver. Ensure the CSEP value is within 0.02 of the MSEP value.</p> <p>Note: If CSEP value is “0” the receiver is unable to calculate the separation between the primary and secondary antennas, and you will not receive a valid heading.</p>

Note: Default settings can be changed to set the time constants to smooth heading, Course-over-Ground (COG), and speed measurements.

CAN Configuration

On the CAN configuration menu, turn ON/OFF CAN and select the baud rate (250 kbps, 500 kbps, or 1000 kbps).



Continued on next page


Configuring the VR1000 Using the WebUI, Continued

Serial

Use Serial to configure the baud rate of each serial port (PortA and PortB) and turn off/on specific NMEA 0183 messages and proprietary Hemisphere BIN messages.

You can also change Port B from RS232 to RS422 and RS422 to RS232 reciprocally.

Configure the Serial Port and click **Output**.



Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Radio Basic


Use Radio Basic to configure the internal UHF radio (protocol, frequency, etc.).

The Radio Configuration defaults to a no-frequency setting.

Use the drop-down arrows to select pre-configured channels. Each channel has an associated frequency, and bandwidth.

Select a protocol (see Table 6: Radio mode). The list of available protocols is dependent upon the bandwidth of your channel. For example, if the bandwidth of the channel you are using is 12.5KHz, Trintalk 2 will not display.

To add new channels, obtain and load a .ucf file from your dealer using the **Upload Config File** button. Choose a channel and select the protocol. For Satel protocol, you may turn FEC OFF/ON.



Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Radio Basic,
continued


Use the following table to configure Radio settings. You may configure any settings in the blue boxes.

Table 6: Radio mode

Radio Mode	Link Rate	Spacing	Modulation	Scrambling	FEC
Trintalk 1	4800 bps	12.5 kHz	GMSK	On	Off
Trintalk 2	9600 bps	25 kHz			
PC1	9600 bps	25 kHz	GMSK	On	On
PC5	4800 bps	12.5 kHz			
PCC-4FSK	9600 bps	12.5 kHz	4FSK	On	On
	19200 bps	25 kHz			
Satel 3AS	9600 bps	12.5 kHz	4FSK	On	Off
	19200 bps	25 kHz			On
					Off
					On

Radio Advanced

Use the Radio Advanced Configuration screen to manually enter Radio frequencies or upload a Configuration file of frequencies. Contact [HGNS Technical Support](#) for Configuration files.



Continued on next page


Configuring the VR1000 Using the WebUI, Continued

Ethernet

Use the VR1000 WebUI to configure the Ethernet connection.


Wi-Fi Bluetooth configuration-configure the WiFi access name, encryption mode, and encryption key of the VR1000 in the WiFi/Bluetooth configuration settings. Click to enable Bluetooth options and type the PIN of the VR1000.

Note: Files cannot be downloaded from the VR1000 filesystem when Bluetooth is enabled.



Logging

Log data to the internal memory of the VR1000 or download a previously saved log.



Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Logging,
continued

Table 7: Logging configuration

Field	Description
GPGGA	Turn on GGA message logging at 0.2Hz, 1Hz, 10Hz, or 20HZ. Note: 10Hz and 20Hz are only available with activations (some kits may come with 10Hz or 20Hz included).
Position/Velocity	Log the position and velocity of the receiver at 0.2Hz, 1Hz, 10Hz, or 20HZ. Note: 10Hz and 20Hz are only available with activations (some kits may come with 10Hz or 20Hz included).
Observations* *This feature is only available if you have a "Raw" activation on the receiver.	Log raw GNSS observations at 0.2Hz, 1Hz, 10Hz, or 20HZ. Note: 10Hz and 20Hz are only available with activations (some kits may come with 10Hz or 20Hz included).
Heading	Heading logs the following messages: <ul style="list-style-type: none"> • GPHDT • GPHDM • GPHDG • HPR • BIN3

Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Logging,
continued

Table 7: Logging configuration (continued)

Field	Description
Ephemeris*	Log raw GNSS ephemeris messages at 0.2Hz, 1Hz, 10Hz, or 20HZ. Note: 10Hz and 20Hz are only available with activations (some kits may come with 10Hz or 20Hz included).
*This feature is only available if you have a "Raw" activation on the receiver.	
Corrections	Log the correction messages coming into the receiver.
High Speed	High Speed logs diagnostic data. Note: Selecting that dropdown option forces the GGA, "corrections" and "ephemeris" options on.
Duration	Set the period for which you wish to record data.
File Splitting	Automatically closes a file and restarts a new file after a period of time. Use file splitting to decrease file sizes or to prevent the loss of a file resulting in the loss of all data.
Filename	Choose a filename. All filenames automatically have an appended date and timestamp.

To stop logging, de-select the **Enabled** button and press **Save Settings**.


⚠ WARNING: If you power off the receiver without properly closing a log, the log file will become corrupted.

Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Ntrip Configuration


Use the Ntrip Configuration screen to enable the receiver to use corrections from an Ntrip Caster.



The screenshot shows the Hemisphere VR1000 web interface. The top navigation bar includes STATUS, TRACKING, INFORMATION, FILES, SYSTEM, and SETTINGS. The left sidebar contains menu items: Heading, CAN, Serial, Radio, Ethernet, Logging, Ntrip (highlighted), Atlas, and Miscellaneous. The main content area displays the 'Ntrip Configuration' screen. The status is 'Disconnected'. There are input fields for Host, Port, Mount Point, User, and Password. At the bottom, there are 'Connection' and 'Undo' buttons.

Atlas tab

You can manually configure the frequency and bandwidth of the L-band satellite you wish to track, or simply click the **Auto** button and let the receiver track automatically.




The screenshot shows the Hemisphere VR1000 web interface. The top navigation bar includes STATUS, TRACKING, INFORMATION, FILES, SYSTEM, and SETTINGS. The left sidebar contains menu items: Heading, CAN, Serial, Radio, Ethernet, Logging, Ntrip, Atlas (highlighted), and Miscellaneous. The main content area displays two configuration screens. The top screen is 'Atlas LBand' with an 'Auto' button and input fields for Frequency (1545.9150) and Bps (600). The bottom screen is 'Atlas Datum' with radio buttons for Datum Type (ITRF08 (default), GDA94, Local Reference Frame) and input fields for Local Offset (X, Y, Z) all set to 0.000. Both screens have 'Save' and 'Undo' buttons.

Continued on next page

Configuring the VR1000 Using the WebUI, Continued

Atlas Datum If using Atlas (not RTK), datum defaults to ITRF08.

You can change Datum Type to GDA94 or enter custom reference frame offsets.



The screenshot shows the Hemisphere VR1000 web interface. At the top, there is a navigation bar with the Hemisphere logo, the device name 'VR1000', and a timer '0:00:00 00:00:00'. Below the navigation bar are tabs for STATUS, TRACKING, INFORMATION, FILES, SYSTEM, and SETTINGS. A sidebar on the left contains menu items: Heading, CAN, Serial, Radio, Ethernet, Logging, Ntrip, Atlas, and Miscellaneous. The main content area is divided into two panels. The top panel is titled 'Atlas LBand' and has an 'Auto' dropdown menu. It contains input fields for 'Frequency' (1545.9150) and 'Bps' (600), with 'Save' and 'Undo' buttons below. The bottom panel is titled 'Atlas Datum' and contains radio buttons for 'Datum Type': 'ITRF08 (default)', 'GDA94', and 'Local Reference Frame (enter offset below)'. Below these are input fields for 'Local Offset' in meters for X, Y, and Z, all set to 0.000, with 'Save' and 'Undo' buttons at the bottom.

Continued on next page

Configuring the VR1000 Using the WebUI, Continued


Miscellaneous **Time Zone-** In the example below, the Time Zone is set to UTC-10, Honolulu - USA time.

To change the Time Zone, click the down arrow, and select the desired time zone. Please note this does not affect UTC time in NMEA output.

Orientation-selects the position in which the receiver is installed.

Device Name-the name of device that displays at the top of the screen.

TCP Server-use to change the listening port.



The screenshot shows the Hemisphere VR1000 WebUI interface. At the top, there is a navigation bar with the Hemisphere logo and the device name 'VR1000'. Below the navigation bar, there are tabs for STATUS, TRACKING, INFORMATION, FILES, SYSTEM, and SETTINGS. The 'Miscellaneous' tab is selected, and a sidebar on the left lists various settings: Heading, CAN, Serial, Radio, Ethernet, Logging, Ntrip, Atlas, and Miscellaneous. The main content area displays four configuration panels, each with a 'Save' button:

- Time Zone:** Zone Select: Honolulu - USA
- Orientation:** Install Orientation: direction A
- Device Name:** Name: VR1000
- TCP Server:** Listening Port: 8080 (with an 'On' toggle switch)

Continued on next page

Appendix A

Terms and definitions

Refer to Table A-1 for a listing of the terms and definitions contained in this document.

Table A-1: Terms and Definitions

Term	Definition
Atlas Frequency	The Atlas™ satellite transmit frequency which ranges from 1525 MHz to 1560 MHz.
Bit Error Rate	The average number of symbol errors per message frame.
Carrier Lock	Indicates the receiver is tracking the satellite frequency.
Frame Sync	Indicates the receiver is properly decoding the Atlas™ data message.

Appendix B

Figure B-1 shows the VR1000 Cable Pin-out assignments.





Figure B-1 Cable Drawing

Note: This cable is **not** available for purchase.

Continued on next page


Appendix B, Continued

Figure B-2 shows the pin assignments for the J1 – J6 connectors.




Continued on next page

Appendix B, Continued



J5
Front View
Port A



J6
Front View
Port B

Figure B2: J1 – J6 Connectors



A TRADITION IN PRECISION

Seattle 425-771-7776 | Tacoma 253-922-6087
Portland 503-641-3388 | Salt Lake City 801-878-9763
St. George 801-878-9763 | Las Vegas 702-586-1152
www.KukerRanken.com